

Temp. Controller &amp; Voltage, Current meter

# CP series

## INSTRUCTION MANUAL

Thank you for purchasing HANYOUNG NUX CO.,Ltd. Product.  
Please check whether the product you purchased is the exactly same as you ordered. Before using product, please read instruction manual carefully.



HEAD OFFICE

1381-3, Juan-Dong, Nam-Gu Incheon, Korea  
TEL: (82-32)876-4697 FAX: (82-32)876-4696

## ■ Safety Information

Please read safety information carefully before use and then use this product properly. Safety information described in this manual contains important contents related with safety. So please follow the instructions accordingly. Safety information is composed of DANGER, WARNING and CAUTION.

### ⚠ DANGER

Do not touch or contact the input/output terminals because it may cause electric shock.

### ⚠ WARNING

- If there is a possibility of an accident caused by errors or malfunctions of this product, install external protection circuit to prevent the accident.
- This product does not contain an electric switch or fuse, so the user needs to install a separate electric switch or fuse externally. (Fuse rating : 250 V 0.5 A)
- To prevent deflection or malfunction of this product, supply proper power voltage in accordance with the rating.
- To prevent electric shock or device malfunction of this product, do not supply the power until the wiring is completed.
- Since this product is not designed with explosion-protective structure, do not use it at any place with flammable or explosive gas.
- Do not decompose, modify, revise or repair this product. This may cause malfunction, electric shock or fire.
- Reassemble this product while the power is off. Otherwise, it may cause malfunction or electric shock.
- If you use the product with methods other than specified by the manufacturer, there may be bodily injuries or property damages.
- Due to the danger of electric shock, use this product installed onto a panel while an electric current is applied.

### ⚠ CAUTION


- The contents of this manual maybe changed without prior notification.
- Before using the product you have purchased, check to make sure that it is exactly what you ordered.
- Check to make sure that there is no damage or abnormality of the product during delivery.
- The ambient temperature is 0 ~ 50 °C and the ambient humidity is 35 ~ 85 % R.H. (No icing).
- Do not use this product at any place with corrosive(especially noxious gas or ammonia) or flammable gas.
- Do not use this product at any place with direct vibration or impact.
- Do not use this product at any place with liquid, oil, medical substances, dust, salt or iron contents. (Use at Pollution level 1 or 2)
- Do not polish this product with substances such as alcohol or benzene.
- Do not use this product at any place with excessive induction trouble, static electricity or magnetic noise.
- Do not use this product at any place with possible thermal accumulation due to direct sunlight or heat radiation.
- Install this product at place under 2,000 m in altitude.
- When the product gets wet, the inspection is essential because there is danger of an electric leakage or fire.
- Use a compensating cable with thermocouple.
- For R.T.D input use a cable which is a small lead wire resistance and without resistance difference to 3 wires.
- To avoid inductive noise to input wires separate from the power and the load wire.
- Keep input wire away from output wire.
- Use a non-earth sensor with thermocouple.
- If there is excessive noise from the power supply, using insulating transformer and noise filter is recommended. The noise filter must be attached to a panel grounded, and the wire between the filter output side and power supply terminal must be as short as possible.
- It is effective to use a twisted cable for power supply against noise.
- Check the alarm function before operating.
- Turn off the power before changing a sensor.
- Use an extra relay when the frequency of operation is rather high. In this case, SSR output type is recommended.
  - Electromagnetic switch : Proportional cycle time is min. 30 sec.
  - SSR : Proportional cycle time is min. 1 sec.
  - Contact output life : Mechanical - Min. 10 million times (no load)
  - Electrical - Min. 100 thousand times (rated load)
- Do not connect anything to the unused terminals.
- After checking polarity of terminal, connect wires at the correct position.
- When this product is connected to a panel, use a circuit breaker or switch approved with IEC947-1 or IEC947-3.
- Install the circuit breaker or switch at near place for convenient use.

- Write down on a label that the operation of circuit breaker or switch disconnects the power since the device is installed.
- For the continuous and safe use of this product, the periodical maintenance is recommended.
- Some parts of this product have limited life span, and others are changed by their usage.
- The warranty period for this product including parts is one year if this product is properly used.
- When the power is on, the preparation period of contact output is required. In case of use for signals of external interlock circuit, use with a delay relay.
- When changing this unit to spare unit, please check again all parameters.

## ■ Suffix Code Structure

Model Name	Suffix code	Description
C P		Temp. controller (Control temperature and display voltage and current)
Dimension	3	(W)96 x (H)48 x (D)102.6 mm
	7	(W)72 x (H)72 x (D)87 mm
Input method	0	Temperature + Voltage + Current
Output method	0	Relay output
	1	SSR / SCR output

## ■ Function and name of each parts



\*1 : In case of CP7 : Green

## ■ Operation method

### ■ Operation Screen

Display	Description
Process value (PV)	Displays process-value.
Setting value *1 (SV)	Display setting value Enter into SV setting mode by pressing <b>SET</b> key Set the target value that want to control by pressing <b>▲</b> , <b>▼</b> and <b>◀▶</b> key

\*1 : Set-Value (SV) is a control target value.  
It is settable within the input range.

### ■ Menu

- Enter into the MENU by pressing **SET** key for 3 seconds in operation screen.
- Return to the operation screen by pressing **SET** key more than 3 seconds in the MENU
- Move to the each of other groups by pressing **▲** and **▼** key.
- Press **SET** to move sub menu of each groups

### 1) Temperature group setup

Process value display unit	Parameter	Setting description	Initial value	Reference
5L E n	Temperature group	-		
5L H	High alarm	Within input range	1300	
5L L	Low alarm	Within input range	-50	
5L P	Proportion band	-100 ~ 100 % of F.S	20	
5L R	Prevent over integral	AUTO, 0.1 ~ 100.0 %	100.0	
5L I	Integral time	1 ~ 6000 sec	240	
5L d	Derivative time	1 ~ 6000 sec	60	
5L b A	Loop Break Alarm	OFF, 1 ~ 7200 sec	480	
5L t	Cycle time	1 ~ 1000 sec	20	RLY : 20 sec SSR / SCR : 2 sec
5L HYS	Hysteresis	0 ~ 10 % of F.S	1	
5L o C	Set data lock	OFF, ON	OFF	

- \*P (proportion band) only when performing proportion control. Set to 0 will convert to ON/OFF control.
- \*A (anti-reset wind up) prevents over shoot and under shoot by integral effectiveness.
- \*I (integral time) decrease offset which caused by proportional control and reaches to the setup value faster.
- \*D (derivative time) predicts change of output so it prevents ripple and improves control safety.
- \*LBA (Loop break alarm) displays setting value of control loop break alarm. OFF setting cancels control loop break alarm.
- \*CT (proportional cycle) displays cycle (sec) of control output. Initial value is changed depends on control output.
- \*HYS (hysteresis) sets adjustment sensitivity of control output (with ON/OFF control)
- \*LOC (Set data lock) turn ON/OFF set data lock function.

### 2) Voltage group setup

Process value display unit	Parameter	Setting description	Initial value	Reference
5L o L	Voltage group	-		
5L b S	voltage input compensation	-100 ~ 100 % of F.S	0	
5L 2	Alarm 2 type	1 ~ 4	1	Refer to Alarm 2
5L 2	Alarm 2 setting value	0 ~ 100 % of F.S	500	
5L HYS 2	Alarm 2 hysteresis	0 ~ 10 % of F.S	3	

- \*Input type : AC voltage input (apply only to sine wave)
- \*Input range : 0 - 500 V a.c


### 3) Current group setup

Process value display unit	Parameter	Setting description	Initial value	Reference
5L A P	Current group	-		
5L b S	Current input compensation	-100 ~ 100 % of F.S	0	
5L H	High current display	0 ~ 300	300	Refer to Alarm 3
5L L	Low current display	A-H > A-L	0	
5L 3	Alarm 3 type	1 ~ 4	1	
5L 3	Alarm 3 setting value	0 ~ 100 % of F.S	300	
5L HYS 3	Alarm 3 hysteresis	0 ~ 10 % of F.S	2	


- \*Input type : AC voltage input (apply only to sine wave) due to CT
- \*Input range : CT Secondary side 0 - 5 A a.c
- \*Voltage input and current input are not insulated. Must use CT.

## ■ Selection of Initial Set Mode


- Enter into initial setting mode by pressing **▲** key and **▼** key for 3 seconds at the same time.
- Return to PV/SV setting mode by pressing **SET** key for 3 seconds or more



\* Please refer to "input type chart" for input type selection.



\* 1. If it is relay output it is fixed with 1. If its output is SSR or SCR then users can select 0 or 1.



Process value (PV) display unit	Description	SV-Display unit (Setting range)	Remark
5L 4	Decimal point Position selection	0 ~ 3	0 → 0000 1 → 000.0 2 → 00.00 1 → 0.000
5L 5	Set the input compensation value	-100 ~ 100 % of F.S	
5L 6	Set the hysteresis of High alarm (ALH)	0 ~ 10 % of F.S	
5L 7	Max temperature setting range	Within Input range	Refer to Input range
5L 8	Min temperature setting range	Within Input range	Refer to Input range
5L 9	Control direction	REV, DIR	0 : Reverse action 1 : Forward action
5L 10	Set the hysteresis of low alarm (ALL)	0 ~ 10 % of F.S	
5L 11	Input filter	OFF, 0 ~ 100 sec	
5L 12	Set the Max. input scale	9999	In case of Voltage input
5L 13	Set the Min. input scale	-1999	In case of Voltage input
5L 14	Set the delay time of High alarm (ALH)	0 ~ 100 sec	
5L 15	Set the delay time of Low alarm (ALL)	0 ~ 100 sec	

- \*If the values of SL1 and SL2 are changed, all parameters of temperature will be initialized. Therefore, SL1 and SL2 should be the first one to be set
- \*In case of DCV input, changing SL12 and SL13 will initialize SL7 and SL8.
- \*Changing alarm type in SL3 will change the alarm value (ALH, ALL)

## ■ Main Functions

### ■ Loop Break Alarm (LBA function)

#### (1) How to set

Set the set value of LBA about twice as Integral Time (I). Also, it is possible to set LBA by auto tuning (AT). In this case, it is going to be set twice as integral time (I) automatically.

#### (2) Operation description

LBA function starts to measure the time from the moment when PID computed value becomes 0 % or 100 %. Also, LBA ON/OFF will be determined according to the changes of process value under the LBA setup time.

- When 100 % of P.I.D computed value continues on more than the LBA setup time and process value does not rise more than 2 °C then LBA will become ON. (with proper operation, LBA will become ON if PV does not get dropped more than 2 °C)
- When 0 % of P.I.D computed value continues on more than the LBA setup time and process value does not drop more than 2 °C then LBA will become ON. (with proper operation, LBA will become ON if PV does not get raised more than 2 °C)

**(3)Operation detail**

LBA function operates under the following conditions

- ① Trouble of controlling object : heater break, no power supply, incorrect wiring and etc.
- ② Sensor trouble : Sensor disconnection, shorted and etc.
- ③ Actuator trouble: burnt relay contact, incorrect wiring, unable to ON or OFF and etc.
- ④ Output circuit trouble : Internally burnt relay contact in the unit, unable to ON or OFF and etc
- ⑤ Input circuit trouble : PV does not get changed when input is changed..

※ In here, causes of the above troubles cannot be identified so please check the control system in consecutive order.

**(4)Cautions for LBA function**

- ① LBA function activated only when PID computed value is 0 % or 100 %. Therefore, the time (from trouble occurrence to LBA activation) equals to the time of computed value of PID becomes 0 % or 100 % plus (addition) LBA setup.
- ② LBA function is not activated while Auto Tuning function is being operated.
- ③ LBA function might be operated even though there are no troubles in the control system and the reason for that is because LBA is influenced by disturbances such as other heat sources and etc
- ④ There are cases when LBA setup time has to be set slightly longer. Such cases are time is short or control object does not match, LBA might be ON/OFF or LBA does not get turn ON.

**■ Set data locking function**

'Set data locking function' prevents front key to change the set value and validate auto tuning. Use it for preventing malfunction after setting up.


**■ Auto - Tuning(AT) function**

Auto-Tuning function measures, computes and sets the most proper integer to P.I.D automatically.

- (1) Run Auto-Tuning after setting P.I.D and ARW
- (2) Pressing key and key at the same time will make AT indicating lamp to flickers and begins Auto-Tuning function
- (3) Once Auto-Tuning is finished, A.T indicating lamp will be turned off automatically and when checking for the integer created by Auto-Tuning in consecutive order, please press key
- (4) When changing integers which set by Auto-Tuning automatically, please change each integer according to the each parameter setup method.
- (5) If users want to stop operating auto-tuning while it is operating, press the key and key at the same time, then A.T lamp will be turned off and auto-tuning will be finished. In this case, each integers of P.I.D does not get changed. (Maintains the values before operating auto-tuning)
- (6) When changing SV (set value) during auto-tuning, auto-tuning will stop operating and control P.I.D (P.I.D which before operating auto-tuning)

**■ Alarm Function**

1) Alarm 1



※ Each alarm could be set as below table  
(▲: Set-value (SV) △: alarm set-value)

Deviation alarm	High and Low alarm	
	Alarm within range	

This is setting method that alarm will start to operate when temperature is higher than certain degree or lower than certain degree regarding SV. For example, if main temperature setting is 200 °C and want to operate within High alarm (ALH) 205 °C and Low alarm (ALH) 190 °C then set 5 °C with ALH and 10 degree Celsius with ALL. At this moment, changing main temperature setting to 300 °C will make alarm to operate when high alarm temperature is 305 °C and low alarm temperature is 290 °C.


Absolute alarm	High and Low alarm	
	Alarm within range	

**Cautions**) it operates within setting temperature of ALH and ALL. Set value does not affect anything.

- ※ Alarm (AL1) relay starts to operate when alarm is being operated.
- ※ Changing alarm type in SL3 will change alarm value (ALH, ALL)

2) Alarm 2


※ Each alarm could be set as below table  
(▲: Set-value (SV)



AL2	Alarm type	operation	standby operation
1	absolute high voltage		X
2	absolute low voltage		X
3	absolute high voltage		O
4	absolute low voltage		O

3) Alarm 3

※ Each alarm could be set as below table  
(▲: Set-value (SV)



AL2	Alarm type	operation	standby operation
1	absolute high current		X
2	absolute low current		X
3	absolute high current		O
4	absolute low current		O

**■ Control Direction**

Select control direction from SL9

- 1) REV : Used when controlling reverse operation and heater
- 2) DR: Used when controlling forward operation and refrigerating machine.

**■ Input Filter**

Select input filter operation time from FILT of temperature group. When indicating value becomes unstable due to effects of noise, the filter helps to eliminate unstable status.

**■ Input Scale**

In case of DCV input, it sets range of displaying inputted voltage.

For example, if input is SL1=0000 (1 - 5 V d.c) and SL12=100.0 and SL13=0.0 then input scale is as follows.

Input voltage	1 V	3 V	5 V
Display	0.0	50.0	100.0


**■ Alarm Delay Time**

Delay time of high alarm and low alarm can be set from SL14 and SL15. Even though it has condition that alarm may occur, if delay time is set in SL14 and SL15 then alarm will operate after delay time is passed. However, alarm cancellation does not have anything to do with delay time.


**■ Anti-Reset Windup (ARW)**

Set the over integral prevention function within A parameter of control group

(1) A = in case of AUTO control



2) In case of set-value is set in A



※ if value of A is too small, huge overshoot or undershoot will occur  
A = please set to 100.0 % value and use it


## Input error and solution

List	Display	Description	Reference
+OVER	OVER → PV	Input OVER	
-OVER	M.OVR → PV	Input -OVER	
RJC Error	RJC → PV	Standard contact Error	Request A/ S
EEPROM Error	EEP → PV	EEPROM Error	Request A/ S
AD Error	ADC.E	AD Error	Request A/ S
SYSTEM Error	SYS.E	SYSTEM Error	Request A/ S
BURN OUT	B.OUT	Sensor Error	Sensor check

## Indicate the exceeded max range of voltage/current


If the measured value of voltage and current rise and exceed max range(108 % of F.S) of voltage/current then measured value of voltage/current will flicker

## Display model when power is supplied




## Dimension and panel cutout

### CP3 (96x48)



### CP7 (72x72)



## Specification

## Input types

classification	SL1	Input types	Range	
			1 °C (SL2 : X1XX)	0.1 °C (SL2 : X1XX)
Thermocouple	0001	K	-50 ~ 1300 °C	-50.0 ~ 999.9 °C
	0101	J	-50 ~ 600 °C	-50.0 ~ 600.0 °C
	1100	E *2	-199 ~ 999 °C	-199.0 ~ 999.0 °C
	1101	T	-50 ~ 400 °C	-50.0 ~ 400.0 °C
	0100	R	0 ~ 1700 °C	0.0 ~ 999.9 °C
	0110	B *1	0 ~ 1800 °C	0.0 ~ 999.9 °C
	0111	S	0 ~ 1700 °C	0.0 ~ 999.9 °C
	1000	L *2	-199 ~ 900 °C	-199.0 ~ 900.0 °C
	1001	N *2	-199 ~ 1300 °C	-199.9 ~ 999.9 °C
	1010	U	-50 ~ 400 °C	-50.0 ~ 400.0 °C
	1011	W	0 ~ 2300 °C	0.0 ~ 999.9 °C
RTD	0010	KPt100	-199 ~ 500 °C	-199.0 ~ 500.0 °C
	0011	Pt100	-199 ~ 640 °C	-199.0 ~ 640.0 °C
DCV	0000	1 - 5 V *3	-1999 ~ 9999	Decimalpoint: according to SL4
	1111	0 - 10 V *3	-1999 ~ 9999	

※Accuracy : ±0.5 % of F.S

※When using 4 - 20 mA input, please connect given 250 Ω resistor to voltage input terminal (+), (-) and select SL1 = 0000 (1 - 5 V d.c input)

\* 1 : within range of 0 ~ 400 °C, ±10 % of F.S


\* 2 : Range of less than 0 °C, ±1 % of F.S

\* 3 : ±1 % of F.S

Power supply	100 - 240 V a.c, 50 - 60 Hz		
Power consumption	Max. 6W		
Temperature Part	Type	Please refer to input chart	
	Sampling Cycle	250 ms	
	Accuracy	±0.5 % (Please refer to input chart)	
	Permissible voltage	20 V d.c for 1 minute	
	Standard junction temperature	±3.5 °C (0 ~ 50 °C)	
	Input disconnection	Up Scale	
	Control output	Relay output	NO : 5 A 250 V a.c, 5 A 30 V d.c (Resistive load) NO : 3 A 250 V a.c, 3 A 30 V d.c (Resistive load) Switching Life : 1 million times (No load)
		Voltage output	ON voltage : Min. 12 V d.c OFF voltage : Max. 0.1 V d.c Resistive load : More than 600 Ω
		Current output	Range : 4 - 20 mA Accuracy : ±0.2 mA Resistive load: Less than 600 Ω
	Current	Type	ON/OFF PID control
		Direction	Reverse action, Forward action
Anti-reset wind-up		AUTO. 0.1 ~ 100.0 %	
A.C voltage input part	Input range	0 - 500 V a.c, 50 - 60 Hz	
	Sampling Cycle	250 ms	
	Accuracy	±1 % of F.S	
	Display accuracy	1 V a.c	
A.C current input part	Input range	Detect by CT sensor (secondary part 0 - 5 A a.c)	
	Sampling Cycle	250 ms	
	Accuracy	±1 % of F.S	
	Display accuracy	1 A a.c	
Alarm output part	Input range	5 A 250 V a.c, 5 A 30 V d.c (Resistive load)	
	Switching Life	1 million times (No load)	
Control resistance	Over 20 MΩ	between primary terminal and secondary terminal	
	Over 20 MΩ	between primary terminal and FG terminal	
	Over 20 MΩ	between secondary terminal and FG terminal	
Dielectric strength	2300 V a.c	between primary terminal and secondary terminal for 1 minute	
	1500 V a.c	between primary terminal and FG terminal	
Measuring category	500 V a.c	between secondary terminal and FG terminal	
	CAT III		
Operating environment	Temp. and humidity	0 ~ 50 °C 35 ~ 85 % R.H.( Without condensation)	
	Environment	Please refer to safety information	

## Connection

### CP3



### CP7

